

INSTALLATION INSTRUCTION

1. Simple installation, don't need to remove the closer from door, or disassemble the arm set.
2. Snap the 'U' retaining clip around the Pinion Nut. Do this by positioning the Retaining Clip so that the flat side is against the closer body and then push the open end of the Clip over the Pinion Nut.
3. Install the cover with the short end of the cover over the valve end of the closer body. The cover will snap into place over the Retaining Clip and Pinion Cap.

